

## MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

By Carol Day at 10:29 am, Dec 05, 2013

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired, end copy to Department of Health and Senior Services; retain original in department file.						
ALCO SENSOR IV SN 030451	PRINTER SN 95.1111.053	DATE OF INSPECTION 12-04-2013				
LOCATION OF INSTRUMENT (STREET AND CITY)		TIME OF INSPECTION				
SOLEARAON ST	JOSEPH, MISSOURI 64501	1410				
CHECKLIST: Place a mark in the box by each item it found to be salisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.						
DIGITAL READOUT (ALL ELEMENTS OPE						
☐ TEMPERATURE OF ALCO SENSOR (1 0.4	C - 40-C)					
PRINTER WORKING PROPERLY						
TIME AND DATE DISPLAYING PROPERLY						
BREATH ALCOHOL ACCURACY STANDARD						
SIMULATOR SOLUTION		SED ETHANOL-GAS MIXTURE				
STANDARD SUPPLIERAIR	GAS LOT # AG3002	201 EXP. DATE 01-02-2015				
SIMULATOR TEMPERATURE (34'C ± 0.2'	C) SIMULATOR SN	SIMULATOR EXP DATE				
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)  0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE						
TEST 1099	EST 2098	TEST 3099				
RFI DETECTOR OPERATING						
INDICATE THE NUMBER OF BREATH TESTS (DO NOT INCLUDE SELF-ADMINISTERED TE	BIN THE FOLLOWING RANGES SINC (STS)	CE THE LAST MAINTENANCE REPORT:				
		(.1519) <sub>0</sub> (OVER .19) <sub>1</sub>				
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).						
. ;						
·		and the state of the state of				
INSPECTING OFFICER						
SIGNATURE		PRINT HAME BRAD KERNS & WAYNE BRYOM				
TYPE IT PERMIT NUMBER/EXPIRATION DATE		TELEPHONE NUMBER				
220427 EXP. 12-27-2014 & 2	20103 EXP 05-09-2014	816-271-5359				
Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office 2875 James Boulevard Poplar Bluff MO 63901						

# Airgas.

Airgas Mid America (LABORATORY)

3500 Bernard Street

St. Louis, Mo. 63103

Ph: (314) 533-3100

Fax: (314) 533-7328

### **Certificate of Analysis**

**Customer Name** Intoximeters, Inc. 2081 Craig Road St. Louis, Mo 63146

2-Jan-2013 Test Date:

Dear Sir,

This is your Certificate of Analysis:

Exp. Date 1/2/2015

Cyl. Type 108

Component Ethanol

Nitrogen

**Certified Concentration** 

 $0.100 \pm 2\%$  BrAC (272 ppm)

Balance

Lot#

AG300201

#### Certification Traceable to N.I.S.T. RGM Ethanol Standards:

Serial No.	Concentration	Serial No.	Concentration
EB0010581	391.5 ppm	EB0010603	390.9 ppm
EB0010570	258.4 ppm	EB0010559	258.3 ppm
EB0010285	208.9 ppm	EB0010595	209.2 ppm
EB0010561	101.9 ppm	EB0010562	104.9 ppm
EB0010681	53.0 ppm	EB0010579	52.4 ppm

NDIR

ISO 17025:2005 A2LA accredited. Certificate Number 2989.01

200 ac 200 c		
	187 10 Serial not 838451 1875 100 201340 63418 1875 100 3615 Time 2181 12/86/13 74121 880 12/86/13 74121 880 15 10/86/15 16:00 886	
	TEST RECORD ROALS  TEST RECORD ROALS  TEST RECORD ROALS  THE Date Rime 2121  TH Blank:  12/84/18 14:24 .888  Calthration Check:  74 12/84/18 14:24 .888	
Constitution Research	Tersion not 7418  Tersion not 7418  Tersion Date Time 2181  Time Date Time 2181  Time 2181  Tersion Checks  Tersion 12/84/18 14:28 .888	

•

.

#### State of Missouri DEPARTMENT OF HEALTH



MO 580-0771 (7-88)



#### **BRAD M KERNS**

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

#### DATAMASTER; ALCO-SENSOR IV W/PRINTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air: Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

12/27/2012	white
Number 220427	Director of State Public Health Leboratory  Lal Vacland, Acting Director
Expires 12/27/2014	Director, Department of Health
MO 500 0771 (7-88)	Lab. 4 (R7-88)

## State of Missouri DEPARTMENT OF HEALTH



## PERMIT TYPE II



#### WAYNE BYROM

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

#### DATAMASTER; ALCO-SENSOR IV W/PRINTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

05/09/2012	wind
Date	Director of State Public Health Laboratory
Expires 05/09/2014	Margaret T. Brunelly  Director, Department of Health
MO 580-0771 (7-88)	Lab. 4 (R7-85)