

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY BREATH ALCOHOL PROGRAM DATAMASTER MAINTENANCE REPORT

RECEIVED

By Carol Day at 9:17 am, May 10, 2013

REPORT#6

Complete this report at the time of the regu Complete this report whenever the instrum Retain the original and send a copy within	ent is serviced o	or repaired and w	henever it is	placed into servi	days). ce.	THE STATE OF THE S
DATAMASTER SN NAME OF AGENCY 201206 SAINT JOSEPH POLICE DEPA			FNT	DATE OF INSPECTION		
201206 SAINT JOSEPH POLICE DEPA LOCATION OF INSTRUMENT (STREET AND CITY)			C14 I	05-09-2013		
501 FARAON STREET SAINT JOSEPH, MISSOURI (.1318		
CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.						
DIAGNOSTIC CHECK (PRINTOUT AT	ΓACHED)	DATE	AND TIME	(from printout)	05-09-201	3 @ 1318
☑ COMPUTER		⊠ D	ETECTOR			
PROGRAM		⊠ FI	LTERS			
HEATERS SAMPLE CHAMBER	48	oc 🛛 Q	JARTZ STAI	NDARD		
FLOW DETECTOR CALIBRATION						
PUMP HIGH SPEED		⊠ PI	RINTER			
SIMULATOR SOLUTION SUPPLIER _	REPCO M	ARKETING	LOT #	12001	EXRDATE_	04-02-2014
SIMULATOR TEMP (34'C ± 0.2'C)	34,0	_ oc SIMULATO	OR SN	SD2278	EXP. DATE _	12-17-2013
CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)						
Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)						
0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE						
TEST 1 w098	TEST 2 a-	.099		TEST 3 w	.10	00
PERFORM R.F.I. TEST (PRINTOUT ATTACHED)						
NDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: DO NOT INCLUDE SELF-ADMINISTERED TESTS)						
REFUSALS 0 (004) 0	(.0509)	(.1014	1	(.1519)	OVE	ER.19 0
IST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR A USE OTHER SIDE IF NECESSARY).	ODIFICATION THAT V	VAS MADE TO RESTOR	THE INSTRUME	NT TO OPERATE SATIS	FACTORILY AND WIT	
DOE OTHER SIDE IF NECESSART).						
						į
NSPECTING OFFICER						
IONATURE			PRINT FULL NAME			
YPE 11 PERMIT NUMBER/EXPIRATION DATE			OFFICER WAYNE BYROM TELEPHONE NUMBER			
220103 05-09-2013			(816) 271-5359			
Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office						
2875 James Blvd, Poplar Bluff MO 63901						

CERTIFICATE OF ANALYSIS

MANUFACTURER AND SUPPLIER: RepCo Marketing, Inc. LOT NUMBER: 12001

EXPIRATION DATE: April 2, 2014 at 11:59 p.m.

RepCo Marketing, Inc. certifies the following:

Number 12001 of Alcohol Certified Solution for simulators. Random samples of said lot number were analyzed by an independent laboratory utilizing a gas chromatograph and found to contain 1205 gms/dl +/-.003 gms/dl wt/vol ethanol (95% Confidence).

The alcohol and distilled water used in the solution were found to be free of any interferring substance.

This solution will produce a vapor alcohol value of <u>.100</u> +/-3% gms/210L Breath when heated to 34 Degrees Celsius +/-0.2 Degrees Celsius in a simulator (95% Confidence).

The date of manufacture for this lot number is April 3, 2012.

The expiration date for this lot number is April 2, 2014 at 11:59 p.m.

This document is a true representation of the original Certificate of

Analysis.

Cecil B. Garner, President RepCo Marketing, Inc.

ICE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI ST. JOSEPH POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201206 05/09/13

REST TIME: 10:00 UBJECT NAME: **RFI/TEST** OB: 10/10/10 SEX: M fATE/D.L.: MO/123456 RESTING OFFICER: BYROMZWZG FFICER I.D.: 7054 :STING OFFICER: BYROM/W/G FICER 1.D.: 7054 ERMIT NUMBER: 220103 (PIRATION DATE: 05/09/14 **ISCELLANEOUS DATA:** RFI TEST

--- BREATH ANALYSIS ---

ANK TEST .000 13:39 TERNAL STANDARD VERIFIED 13:39 IDIO INTERFERENCE

OR SIGNATURE

REORDER ALL SUPPLIES FROM N.P.A.S. P.O. BOX 1435, MANSFIELD, OH 44901

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI ST. JOSEPH POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201206 05/09/13 13:18

--- DIAGMOSTIC CHECK ---

COMPUTER:

OKAY

PROGRAM (04-07-2009):

OKAY

HEATERS

SAMPLE CHAMBER:

48c

FLOW DETECTOR:

OKAY

PUMP

HIGH SPEED:

OKAY

DETECTOR:

OKAY

FILTERS:

OKAY

QUARTZ STANDARD:

OKAY

CALIBRATION:

OKAY

PRINTER TEST

!"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFG HIJKLMNOPQRSTUVWXYZ[\]^_'abcdefqhi.iklmno pqrstuvwxyz{I}>~

OPERATOR SIGNATURE

Card Stock No.

REORDER ALL SUPPLIES FROM N.P.A.S. P.O. BOX 1435, MANSFIELD, OH 44901

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI ST.JOSEPH POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201206 05/09/13

TESTING OFFICER:
BYROM/W/G
OFFICER I.D.: 7054
PERMIT NUMBER: 820103
EXPIRATION DATE: 05/09/14
MISCELLAMEOUS DATA:

--- SUPERVISOR MODE ----

BLANK TEST	.000	13:44
INTERNAL STANDARD	VERIFIED.	13:44
EXTERNAL STANDARD	.098	13:44
BLANK TEST	.000	13:45
EXTERNAL STANDARD	.099	13:45
BLÁNK TEST	.000	13:46
EXTERNAL STANDARD	.100	13:47
BLANK TEST	. 999	13:47

¹M = 3 SIM. = .1 AVG. = .099

OPERATOR SIGNATURE

Card Stock No. 60021

REORDER ALL SUPPLIES FROM N.P.A.S. P.O. BOX 1435, MANSFIELD, OH 44901

State of Missouri DEPARTMENT OF HEALTH



PERMIT TYPE II



WAYNE BYROM

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER; ALCO-SENSOR IV W/PRINTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

05/09/2012	Wonde				
Number 220103	Director of State Public Health Laboratory Margaret T. Donnelly				
Expires 05/09/2014	Director, Department of Health				
MO 580-0771 17-98\	lah. 4/R7-A				