

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

By Carol Day at 10:13 am, May 28, 2014

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file. DATE OF INSPECTION PRINTER SN ALCO SENSOR IV SN 05/27/2014 071.3383,132 078369 TIME OF INSPECTION LOCATION OF INSTRUMENT (STREET AND CITY) 7:40 am 4525 Downs Drive St. Joseph, MO 64507 CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument. DIGITAL READOUT (ALL ELEMENTS OPERATIONAL) TEMPERATURE OF ALCO SENSOR (10°C - 40°C) PRINTER WORKING PROPERLY ▼ TIME AND DATE DISPLAYING PROPERLY BREATH ALCOHOL ACCURACY STANDARDS COMPRESSED ETHANOL-GAS MIXTURE SIMULATOR SOLUTION EXP. DATE 06/19/2015 STANDARD SUPPLIER RepCo Marketing, Inc. LOT # 13002 SIMULATOR EXP DATE 12/06/2014 SD3506 34.0 SIMULATOR SN SIMULATOR TEMPERATURE (34°C ± 0.2°C) _ ☑ CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE TEST 3 - .096 TEST 2 .095 TEST 1 # .097 RFI DETECTOR OPERATING INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS) (OVER .19) (.10-.14)(.15 - .19)(.05 - .09)(0-.04)REFUSALS List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary). Instrument is operating within the limits set forth by the Missouri Department of Health and Senior Services. Solution provided by RepCo Marketing, Inc. .100 Solution, Lot# 13002 expires 06/19/2015. PRINT NAME SIGNATUSE James Bench TELEPHONE NUMBER (816) 271-4438 son to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office

2875 James Boulevard

Albakar Bluff, NO 63901

CERTIFICATE OF ANALYSIS

MANUFACTURER AND SUPPLIER: RepCo Marketing, Inc. LOT NUMBER: 13002
EXPIRATION DATE: June 19, 2015 at 11:59 p.m.

RepCo Marketing, Inc. certifies the following:

RepCo Marketing, Inc. manufactured, tested and supplied Lot Number 13002 of Alcohol Certified Solution for simulators. Random samples of said lot number were analyzed by an independent laboratory utilizing a gas chromatograph and found to contain ______ gms/dl +/-.003 gms/dl wt/vol ethanol (95% Confidence).

The alcohol and distilled water used in the solution were found to be free of any interferring substance.

This solution will produce a vapor alcohol value of _.100 +/-3% gms/210L Breath when heated to 34 Degrees Celsius +/-0.2 Degrees Celsius in a simulator (95% Confidence).

The date of manufacture for this lot number is <u>June 20, 2013</u>

The expiration date for this lot number is <u>June 19, 2015</u> at 11:59 p.m.

This document is a true representation of the original Certificate of Analysis.

Cecil B. Garner, President RepCo Marketing, Inc.

Form RM 02

this some so Just h 100 64507 Jan Sh x117 St Torych MO 64567 4525 DRWY 5 DT ... 4725 Dawns Dr St. Joseph who beginn Att Dewis of or Joseph Marios



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES **BREATH ALCOHOL PROGRAM**



PERMIT TYPE II

JAMES E BENCH

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 2/11/2014	Lunde
	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
NUMBER 240032	Dail Vasterly
EXPIRES 2/11/2016	J
	DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 580-0771 (6-10)

LAB-4 (R6-10)





BENCH, JAMES Operator Permit No 240032

Date Issued 2/11/2014

Date Expires 2/11/2016