



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES  
STATE PUBLIC HEALTH LABORATORY  
**ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT**

**RECEIVED**

REPORT #7  
By Carol Day at 1:15 pm, Aug 14, 2014

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN 087976	PRINTER SN 08C.3527.185	DATE OF INSPECTION 07/31/2014
LOCATION OF INSTRUMENT (STREET AND CITY) Toad Cove Zone Office, Bittersweet Road, Lake Ozark		TIME OF INSPECTION 10:20 pm

**CHECKLIST:** Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

☒ DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

☒ TEMPERATURE OF ALCO SENSOR (10°C - 40°C)

☒ PRINTER WORKING PROPERLY

☒ TIME AND DATE DISPLAYING PROPERLY

**BREATH ALCOHOL ACCURACY STANDARDS**

☒ SIMULATOR SOLUTION ☐ COMPRESSED ETHANOL-GAS MIXTURE

☒ STANDARD SUPPLIER Guth Laboratories, Inc. LOT # 13290 EXP. DATE 10/29/2015

☒ SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34 SIMULATOR SN 1292 SIMULATOR EXP DATE 01/03/2015

☒ CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- ☒ 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE  
☐ 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE  
☐ 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 ➡ .101%

TEST 2 ➡ .102%

TEST 3 ➡ .101%

☒ RFI DETECTOR OPERATING

**INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:  
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)**

REFUSALS	1	(0-.04)	0	(.05-.09)	0	(.10-.14)	0	(.15-.19)	0	(OVER .19)	0
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

**INSPECTING OFFICER**

SIGNATURE [Signature]

PRINT NAME  
Trooper C. Richardson

TYPE IF PERMIT NUMBER/EXPIRATION DATE  
230335 / 12/23/2014

TELEPHONE NUMBER  
(573) 751-1000

**Return completed report to the:** Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office  
2875 James Boulevard  
Poplar Bluff, MO 63901

AS IV Serial no: 087976  
Version no: 004C

TEST RECORD 00586

Temp Date Time 210L

Air Blank:

07/31/14 22:23 .000

Calibration Check:

23 07/31/14 22:23 .101

Subject Name

Subject I.D.

Operator Name I.D.

Location

AS IV Serial no: 087976  
Version no: 004C

TEST RECORD 00587

Temp Date Time 210L

Void: RFI

12 07/31/14 22:24

Subject Name

Subject I.D.

Operator Name I.D.

Location

AS IV Serial no: 087976  
Version no: 004C

TEST RECORD 00584

Temp Date Time 210L

Air Blank:

07/31/14 22:20 .000

Calibration Check:

21 07/31/14 22:20 .101

Subject Name

Subject I.D.

Operator Name I.D.

Location

AS IV Serial no: 087976  
Version no: 004C

TEST RECORD 00585

Temp Date Time 210L

Air Blank:

07/31/14 22:21 .000

Calibration Check:

22 07/31/14 22:21 .102

Subject Name

Subject I.D.

Operator Name I.D.

Location



**GUTH LABORATORIES, INC.**

809 NORTH 5TH STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-364-5470

## **CERTIFICATE OF ANALYSIS**

**Certified Alcohol Reference Solution for Simulator**

Random Samples of Lot Number 13290 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 31, 2013, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1202% (w/vol) ethyl alcohol. The expiration date for this lot number is October 29, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President  
GUTH LABORATORIES, INC.

***NIST Traceability:***

*Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.*

*All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.*