



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

REPORT #7

Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever instrument is repaired. Send copy to Department of Health and Senior Services; retain original in department file.

ALCO SENSOR IV SN <u>St. Louis County</u> <u>108388</u> <u>Police Dept.</u>	PRINTER SN <u>099.3586.815</u>	DATE OF INSPECTION <u>10-12-2014</u>
LOCATION OF INSTRUMENT (STREET AND CITY) <u>Vehicle # T696, at 8007 W. Florissant</u> <u>Jennings, MO</u> <u>63136</u>		TIME OF INSPECTION <u>20:11</u>

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

☒ DIGITAL READOUT (ALL ELEMENTS OPERATIONAL)

☒ TEMPERATURE OF ALCO SENSOR (10°C - 40°C) 18°C

☒ PRINTER WORKING PROPERLY

☒ TIME AND DATE DISPLAYING PROPERLY

BREATH ALCOHOL ACCURACY STANDARDS

☒ SIMULATOR SOLUTION

☐ COMPRESSED ETHANOL-GAS MIXTURE

☒ STANDARD SUPPLIER Guth Laboratories LOT # 14030 EXP. DATE 01-20-16

☒ SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34.0°C SIMULATOR SN SD2289 SIMULATOR EXP DATE 07-17-15

☒ CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- ☒ 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE
☐ 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE
☐ 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE

TEST 1 = .099

TEST 2 = .100

TEST 3 = .102

☒ RFI DETECTOR OPERATING

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	1	(0-.04)	—	(.05-.09)	—	(.10-.14)	1	(.15-.19)	1	(OVER .19)	1
----------	---	---------	---	-----------	---	-----------	---	-----------	---	------------	---

List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

INSPECTING OFFICER

SIGNATURE

P. D. ROSE 2721

PRINT NAME

Officer D. ROSE, 2721

TYPE II PERMIT NUMBER/EXPIRATION DATE

230253 / 11-12-2015

TELEPHONE NUMBER

(314) 889-2341

Return completed report to the: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Boulevard
Poplar Bluff, MO 63901

AS IV Serial no: 108388
Version no: 532B

TEST RECORD 00092

Temp	Date	Time	s/
		210L	

Air Blank:
10/12/14 20:11 .000
Calibration Check:
18 10/12/14 20:11 .099

Subject Name

N/A

Subject I.D.

N/A

Operator Name, I.D.

ROSC 2721

Location

8007 W. Floissant

#T696

AS IV Serial no: 108388
Version no: 532B

TEST RECORD 00093

Temp	Date	Time	s/
		210L	

Air Blank:
10/12/14 20:12 .000
Calibration Check:
19 10/12/14 20:12 .100

Subject Name

N/A

Subject I.D.

N/A

Operator Name, I.D.

ROSC 2721

Location

8007 W. Floissant

#T696

AS IV Serial no: 108388
Version no: 532B

TEST RECORD 00094

Temp	Date	Time	s/
		210L	

Air Blank:
10/12/14 20:15 .000
Calibration Check:
20 10/12/14 20:15 .102

Subject Name

N/A

Subject I.D.

N/A

Operator Name, I.D.

ROSC 2721

Location

8007 W. Floissant

#T696

AS IV Serial no: 108388
Version no: 532B

TEST RECORD 00095

Temp	Date	Time	s/
		210L	

VOID: RFI
12 10/12/14 20:18

Subject Name

N/A

Subject I.D.

N/A

Operator Name, I.D.

ROSC 2721

Location

8007 W. Floissant

#T696



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 14030 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on January 22, 2014, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1215% (w/vol) ethyl alcohol. The expiration date for this lot number is January 20, 2016 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



Simulator Calibration Report

This calibration report is to certify the alcohol reference simulator listed below has been examined and tested using standards traceable to the National Institute of Standards and Technology (NIST) in accordance with the standards set by the Missouri Department of Health and Senior Services Rules and Regulations:
19 CSR 25-30.051 (4).



Technician Printed Name: Donald D. DeBoard

Technician Signature: Donald D. DeBoard

Date: 7-17-2014

Contact: Missouri Safety Center
Breath-Alcohol Instrument Training Program
660-543-4834



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

2

PERMIT
TYPE II
DAVID M ROSE

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

DATAMASTER, INTOX DMT, ALCO-SENSOR IV W/PRINTER


for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.


DATE 11/12/2013

NUMBER 230253

EXPIRES 11/12/2015

MO 880-0771 (6-10)



DIRECTOR OF STATE PUBLIC HEALTH LABORATORY


,acting director
DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

LAB-4 (R6-10)