

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY **BREATH ALCOHOL PROGRAM**

DATAMASTER MAINTE	MANCE REPORT			REPORT #6
Complete this report at the time of the regu Complete this report whenever the instrume Retain the original and send a copy within 1	ent is serviced or repaired	l and whenever it is i	place By Carol Day at 8:	06 am, Jun 02, 2014
DATAMASTER SN NAME OF AGENCY 201281 Branson Poli	ce Department		DATE OF INSPECTION 06/02/2014	
LOCATION OF INSTRUMENT (STREET AND CITY)			TIME OF INSPECTION	
110 W. Maddux Suite 100, Branson, M CHECKLIST: Place a mark in the box by each		factory or if operating	3:15 am	its (Write in observed values
where determined.) Unmarked items must be				
DIAGNOSTIC CHECK (PRINTOUT AT	DATE AND TIME (from printout) 6/2/2014 0332			
☑ COMPUTER		DETECTOR		
☑ PROGRAM		☑ FILTERS		
☑ HEATERS SAMPLE CHAMBER	<u>49</u> °C	QUARTZ STAN	IDARD	
☑ FLOW DETECTOR		☑ CALIBRATION		
☑ PUMP HIGH SPEED		✓ PRINTER		
☑ INDICATOR LIGHTS				
SIMULATOR SOLUTION SUPPLIER	Suth Laboratories Inc	LOT # <u>1</u>	3280 EXP.	DATE 10/16/2015
SIMULATOR TEMP (34°C ± 0.2°C)	34.0 °C SII	MULATOR SN	SD2728 EXP.	DATE 12/11/2014
☑ CALIBRATION CHECK – (ONLY ONE S	STANDARD IS TO BE US	SED PER MAINTEN	ANCE REPORT)	
Run three tests using a standard solution less. Mark the box corresponding to the 0.100% STANDARD - MUST READ 0.080% STANDARD - MUST READ 0.040% STANDARD - MUST READ	standard solution being L BETWEEN 0.095% AND BETWEEN 0.076% AND	used. (PRINTOUT A 0.105% INCLUSIVE 0.084% INCLUSIVE	ITACHED) : :	ist have a spread of .005 or
TEST 1 ☞ .101	TEST 2 ■ .102		TEST 3 .102	
PERFORM R.F.I. TEST (PRINTOUT AT	TACHED)			
INDICATE THE NUMBER OF BREATH TE (DO NOT INCLUDE SELF-ADMINISTERED	STS IN THE FOLLOWING	G RANGES SINCE	THE LAST MAINTENA	ANCE REPORT:
REFUSALS 0 (004) 0	(.0509) 0	(.1014) 1	(.1519) 2	OVER .19 2
LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR (USE OTHER SIDE IF NECESSARY). Instrument Operating in Specifications	MODIFICATION THAT WAS MADE TO	O RESTORE THE INSTRUME	NT TO OPERATE SATISFACTOR	ILY AND WITHIN ESTABLISHED LIMITS
INSPECTING OFFICER SIGNATURE 1		PRINT FULL NA	ME	
, Shurdyn Kand	Stanley R. Kauffman			
TYPE II PERMIT NUMBERIEKPIRATION OATE 220426 12/27/2		TELEPHONE NUMBER (417) 334-3300		
28	reath Alcohol Program, M 375 James Blvd. oplar Bluff, MO 63901	O Department of He	alth and Senior Servic	es, Southeast District Office

MO 580-1468 (2-08)



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 13280 of
Alcohol Reference Solution for Simulator were analyzed by
gas chromatography on October 18, 2013, using a Perkin Elmer Gas
Chromatograph Autosystem XL S/N: 610N9030209, and found to contain
0.1217% (w/vol) ethyl alcohol. The expiration date for this lot
number is October 16, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

State of Missouri **DEPARTMENT OF HEALTH**



R M TYPE II



Lab. 4 (R7-88)

STANLEY R KAUFFMAN

DATAMASTER

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986. 12/27/2012 Director of State Public Health Laboratory Number 220426 ACTING DIRECTOR Expires 12/27/2014 Director, Department of Health MO 580-0771 (7-88)

Face This Side Down – This Edge In First

BAC DataMasterEvidence Ticket

STATE OF MISSOURI BRANSON POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201281 06/02/14

TESTING OFFICER:

KAUFFMAN/STANLEY/R

OFFICER I.D.: 215

PERMIT NUMBER: 220426

EXPIRATION DATE: 12/27/14

MISCELLANEOUS DATA:

--- SUPERVISOR MODE ---

BLANK TEST	.000	03:34
INTERNAL STANDARD	VERIFIED	03:34
EXTERNAL STANDARD	.101	03:35
BLANK TEST	.000	03:36
EXTERNAL STANDARD	.102	03:36
BLANK TEST	.000	03:36
EXTERNAL STANDARD	.102	03:37
BLANK TEST	.000	03:37

' N = 3 SIM. = .1 AVG. = .1016 Face This Side Down - This Edge In First

BAC DataMasterEvidence Ticket

STATE OF MISSOURI BRANSON POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201281 06/02/14 03:32

--- DIAGNOSTIC CHECK ---

COMPUTER:

OKAY

PROGRAM (04-07-2009):

OKAY

HEATERS

SAMPLE CHAMBER:

49c

FLOW DETECTOR:

OKAY

PUMP

HIGH SPEED:

OKAY

DETECTOR:

OKAY

FILTERS:

OKAY

QUARTZ STANDARD:

OKAY

CALIBRATION:

OKAY

PRINTER TEST

!"#\$%%'()*+,-./0123456789:;<=>?@ABCDEFG HIJKLMNOPQRSTUVWXYZ[$\]$ 'abcdefghijklmnopqrstuvwxyz{ $\}$

Operator Signature Selection Signature

Operator Signature \$\int \begin{array}{c} \pmu \\ \pmu

Face This Side Down – This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI BRANSON POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201281 06/02/14

ARREST TIME: 03:15 SUBJECT NAME: RFITEST

DOB: 10/10/10 SEX: M STATE/D.L.: MO/

ARRESTING OFFICER: KAUFFMAN/STANLEY/R OFFICER I.D.: 215 TESTING OFFICER:

KAUFFMAN/STANLEY/R OFFICER I.D.: 215 PERMIT NUMBER: 220426 EXPIRATION DATE: 12/27/14 MISCELLANEOUS DATA:

--- BREATH ANALYSIS ---

BLANK TEST INTERNAL STANDARD RADIO INTERFERENCE .000

03:40

VERIFIED 03:40

Operator Signature