



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
BREATH ALCOHOL PROGRAM
DATAMASTER MAINTENANCE REPORT

received 6/21/14-cd

REPORT #6

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days).
Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service.
Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

REVIEWED

By Carol Day at 7:56 am, Jul 11, 2014

DATAMASTER SN 204135	NAME OF AGENCY MISSOURI STATE HIGHWAY PATROL	DATE OF INSPECTION 06/11/2014
LOCATION OF INSTRUMENT (STREET AND CITY) PIKE COUNTY SHERIFF'S DEPARTMENT, BOWLING GREEN, MO 6334		TIME OF INSPECTION 7:32 pm

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC CHECK (PRINTOUT ATTACHED)	DATE AND TIME (from printout) 06/11/2014 1932
<input checked="" type="checkbox"/> COMPUTER	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTERS
<input checked="" type="checkbox"/> HEATERS SAMPLE CHAMBER 49 °C	<input checked="" type="checkbox"/> QUARTZ STANDARD
<input checked="" type="checkbox"/> FLOW DETECTOR	<input checked="" type="checkbox"/> CALIBRATION
<input checked="" type="checkbox"/> PUMP HIGH SPEED	<input checked="" type="checkbox"/> PRINTER

☒ INDICATOR LIGHTS

☒ SIMULATOR SOLUTION SUPPLIER GUTH LABORATORIES LOT # 13290 EXP. DATE 10/29/2015

☒ SIMULATOR TEMP (34°C ± 0.2°C) 34.0 °C SIMULATOR SN G6831 EXP. DATE 04/23/2015

☒ CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- ☒ 0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE
☐ 0.080% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE
☐ 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE

TEST 1 .098

TEST 2 .100

TEST 3 .100

☒ PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	1	(.05-.09)	1	(.10-.14)	3	(.15-.19)	0	OVER .19	1
----------	---	---------	---	-----------	---	-----------	---	-----------	---	----------	---

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS
(USE OTHER SIDE IF NECESSARY).

INSPECTING OFFICER

SIGNATURE
TPR P. C. Long
TYPE II PERMIT NUMBER/EXPIRATION DATE
220151 06/26/2014

PRINT FULL NAME
TPR. P. C. LONG
TELEPHONE NUMBER
(636) 300-2800

RETURN COMPLETED REPORT TO THE:

Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Blvd.
Poplar Bluff, MO 63901



GUTH LABORATORIES, INC.

690 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-664-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 13290 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 31, 2013, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1202% (w/vol) ethyl alcohol. The expiration date for this lot number is October 29, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

BAC DataMaster

Evidence Ticket

MISSOURI STATE HIGHWAY PATROL
BAC DATAMASTER SERIAL NUMBER 284135

06/11/14
19:32

--- DIAGNOSTIC CHECK ---

COMPUTER: OKAY
PROGRAM (04-37-2009): OKAY
HEATERS
SAMPLE CHAMBER: 49C
FLOW DETECTOR: OKAY
PUMP
HIGH SPEED: OKAY
DETECTOR: OKAY
FILTERS: OKAY
DURRIZ STANDARD: OKAY
CALIBRATION: OKAY

PRINTER TEST

1486287<>+.-,0123456789:;<=>?@ABCDEFGHI
JKLMNOPQRSTUVWXYZ[\]^_`abcde{ghijklmno
pqrstuvwxyz{|}~"

Operator Signature

For PC Long

DOB: 12/23/85 SEX: M
STATE/D.O.B.: MO/XXXX/XXXXXX
ARRESTING OFFICER:
LONG/P/C
OFFICER I.D.: 875
TESTING OFFICER:
LONG/P/C
OFFICER I.D.: 875
PERMIT NUMBER: 220151
EXPIRATION DATE: 06/26/14
MISCELLANEOUS DATA:
RFI TEST

PERMIT NUMBER: 220151
EXPIRATION DATE: 06/26/14
MISCELLANEOUS DATA:

--- SUPERVISOR MODE ---

BLANK TEST	.000	19:36
INTERNAL STANDARD	VERIFIED	19:36
EXTERNAL STANDARD	.098	19:36
BLANK TEST	.000	19:37
EXTERNAL STANDARD	.100	19:38
BLANK TEST	.000	19:38
EXTERNAL STANDARD	.100	19:39
BLANK TEST	.000	19:39

--- BREATH ANALYSIS ---

BLANK TEST	.000	19:41
INTERNAL STANDARD	VERIFIED	19:41
RADIO INTERFERENCE		

n = 3
SIM. = .1
RMS. = .0993

Operator Signature

For PC Long

Operator Signature

For PC Long

State of Missouri
DEPARTMENT OF HEALTH



P E R M I T
TYPE II



PAUL C LONG

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field repairs, and operate the following breath analyzer(s):

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired (alveolar) air. Issued under the provisions of sections 577.020 through 577.041, RSMo 1986.

Date 06/26/2012

Number 220151

Expires 06/26/2014

MO 680-0771 (7-88)

Director of State Public Health Laboratory

Director, Department of Health

Lab. 4 (R7-88)