

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES STATE PUBLIC HEALTH LABORATORY BREATH ALCOHOL PROGRAM

DECEIVED

SALATITALCONOL PROGRAM	KECEIVED
DATAMASTER MAINTENANCE REPORT	By Carol Day at 8:13 am, Oct 31, 201

COMPlete this report	at the time of the regular whenever the instrument d send a copy within 15	t is sendeed or rea:	sited and whonour, it	la alasadini.	days). ⁄ice.		
DATAMASTER SN 204135			DATE OF INSPECTION 10/29/2014				
LOCATION OF INSTRUMENT Pike County Sheril	STREET AND CITY) S Department, Bowlin	ig Green, Missou	rì	TIME OF INSPECTION			
CHECKLIST: Place a	mark in the box by each i nmarked items must be	item if found to be s	atisfactory or if operat	ing within establish	ned limits. (Write in obser	ved value
2a	IECK (PRINTOUT ATTA			(from printout) 1	0/29/2014	2035	
☑ COMPUTER			DETECTOR				
☑ PROGRAM			FILTERS				
☑ HEATERS SA	MPLE CHAMBER	<u>49</u> °C	2 QUARTZ STA	ANDARD			
	TOR		Z CALIBRATIO	V			
☑ PUMP HIGH S	PEED		PRINTER		····		
☑ INDICATOR LIGH	rs	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
SIMULATOR SOL	JTION SUPPLIER Guth	ı Labs, INC.	LOT#_	13290	EXP. DAT	E_10/29/201	5
☑ SIMULATOR TEM	° (34°C ± 0.2°C)	34.2 °C	SIMULATOR SN	G6768		E 04/23/201	
☑ CALIBRATION CHI	CK - (ONLY ONE STAN	VDARD IS TO BE	USED PER MAINTEN	ANCE REPORT)			
Run three tests using less. Mark the box	ig a standard solution. A orresponding to the stan	ill three tests must idard solution being	be within ±5% of the g used. (PRINTOUT A	standard value ar TTACHED)	nd must ha	ve a spread o	f .005 or
☐ 0.080% STANDA	RD - MUST READ BET RD - MUST READ BET RD - MUST READ BET	WEEN 0.076% AN	D 0.084% INCLUSIVE	•			
TEST 199	TES	ST 2 ☎ .100		TEST 3 ₩ .100			
PERFORM R.F.I. TE	ST (PRINTOUT ATTACH	fED)	***************************************				
INDICATE THE NUMBE (DO NOT INCLUDE SE	R OF BREATH TESTS I F-ADMINISTERED TES	IN THE FOLLOWII	NG RANGES SINCE	THE LAST MAIN	renance	REPORT:	
REFUSALS 0 (0	04) 0 (.05	09) 1	(.10-,14) 1	(.1519)	1	OVER .19	0
LIST ANY NEW PARTS AND DESC (USE OTHER SIDE IF NECESSAR)	BE ANY ALTERATION OR MODIF	CATION THAT WAS MADE	TO RESTORE THE INSTRUME	TT TO OPERATE SATISFA	CTORILY AND	WITHIN ESTABLISH	ED LIMITS
NSPECTING OFFICER			WEST (\$100 H-152); SEE				
SIGNATURE AND INC.	38 F-8	355	Cpl. B, W.	E Long #855			
TYPE II PERVIT NOTIGER EXPIRAT 230035	02/27/2015		(636) 300	VBER			
RETURN COMPLETED REPOR	2875 Ja	Alcohol Program, M imes Blvd. Bluff, MO 63901	MO Department of Hea	IIIh and Senior Se	rvices, Sot	itheast Distric	Office



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 13290 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on October 31, 2013, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1202% (w/vol) ethyl alcohol. The expiration date for this lot number is October 29, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C 4/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL BAC DATAMASTER SERIAL NUMBER 204135 10/29/14 20:35

--- DIAGNOSTIC CHECK ---

COMPUTER:

OKAY

FROGRAM (04-07-2009):

OKAY

HEATERS

SAMPLE CHAMBER:

49c

FLOW DETECTOR:

OKAY

PUNP

HIGH SPEED:

OKAY

DETECTOR:

OKAY

FILTERS:

OKAY

QUARTZ STANDARD:

OKAY

CALIBRATION:

OKAY

PRINTER TEST

!"#\$%%'()*+.-./0123456789::<=>?@ABCDEFG HIJKLMNOPQRSTUVWXYZ[\]^_\abcdefqhi.iklmno oqrstuvwxuz(|)+

Operator Signature_

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL BAC DATANASTER SERIAL NUMBER 204135 10/29/14

TESTING OFFICER:
LONG/B/W
OFFICER 1.D.: 855
PERMIT NUMBER: 230035
EXPIRATION DATE: 02/27/15
MISCELLANEOUS DATA:

--- SUPERVISOR MODE ---

BLANK TEST	. 998	29:49
INTERNAL STANDARD	VERIFIED	20:40
EXTERNAL STANDARD	.099	26:49
PLANK TEST	, ଉପର	20:41
EXTERNAL STANDARD	.100	29:42
BLANK TEST	.000	20:42
EXTERNAL STANDARD	.100	20:43
BLANK TEST	. 000	20:43

M = 3 SIM. = .1 _____AVG. = .0996

Operator Signature CTB.W.Sg #855

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL BAC DATAMASTER SERIAL NUMBER 204135 10/29/14

ARREST TIME: 20:25 SUBJECT NAME:

NONE

DOB: 01/01/01

SEX: N

STATE/D.L.: MO/NONE ARRESTING OFFICER:

HONE

OFFICER I.D.: NONE TESTING OFFICER:

LONG/B/W

OFFICER I.D.: 855

PERMIT NUMBER: 230035

EXPIRATION DATE: 02/27/15

MISCELLANEOUS DATA:

RADIO INTERFERENCE TEST

--- BREATH AMALYSIS ---

BLANK TEST -INTERNAL STANDARD RADIO INTERFERENCE

20:47 .000

VERIFIED 20:47

BAC DataMaster Evidence Ticket

MISSOURI STATE HIGHWAY PATROL BAC DATAMASTER SERIAL NUMBER 204135 10/29/14

ARREST TIME: 20:25
SUBJECT NAME:
NOME
DOB: 01/01/01 SEX: N
STATE/D.L.: MO/NA
ARRESTING OFFICER:
NOME
OFFICER I.D.: NOME
TESTING OFFICER:
LONG/B/W
OFFICER I.D.: 855
PERMIT NUMBER: 230035
EXPIRATION DATE: 02/27/15
MISCELLANEOUS DATA:

SELF TEST

--- BREATH ANALYSIS ---

BLANK TEST	.000	50:21
INTERNAL STANDARD	VERIFIED	20:5i
OUN DOOT SOMPLE	. 000	20:52
TI ANK TEST	.000	20:52

Operator Signature_

#855

...



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES BREATH ALCOHOL PROGRAM



is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs. BRYAN W LONG

DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

MO 580-0771 (6-10)	EXPIRES 02/27/2015	NUMBER230035	DATE 02/27/2013
DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES	Adar Versterling	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY	Wa W

LAB-4 (R6-10)