



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
BREATH ALCOHOL PROGRAM
DATAMASTER MAINTENANCE REPORT

RECEIVED 1/14/14 REPORT #5

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days).
Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service.
Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

REVIEWED
By Carol Day at 8:13 am, Feb 04, 2014

DATAMASTER SN 940061	NAME OF AGENCY Moberly Police Department	DATE OF INSPECTION 01/07/2014
-------------------------	---	----------------------------------

LOCATION OF INSTRUMENT (STREET AND CITY) 300 N Clark St., Moberly Mo 65270	TIME OF INSPECTION 5:02 am
---	-------------------------------

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

☒ DIAGNOSTIC CHECK (PRINTOUT ATTACHED) DATE AND TIME (from printout) 01/07/2014 05:02

☒ COMPUTER

☒ DETECTOR

☒ PROGRAM

☒ FILTERS

☒ HEATERS SAMPLE CHAMBER 49 °C

☒ QUARTZ STANDARD

☒ FLOW DETECTOR

☒ CALIBRATION

☒ PUMP HIGH SPEED

☒ PRINTER

☒ INDICATOR LIGHTS

☒ SIMULATOR SOLUTION SUPPLIER Guth Laboratories LOT # 13100 EXP. DATE 04/23/2015

☒ SIMULATOR TEMP (34°C ± 0.2°C) 34.0 °C SIMULATOR SN SD1500 EXP. DATE 08/02/2014

☒ CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

☒ 0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE

☐ 0.080% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE

☐ 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE

TEST 1 .100

TEST 2 .099

TEST 3 .100

☒ PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS	0	(0-.04)	0	(.05-.09)	1	(.10-.14)	2	(.15-.19)	2	OVER .19	3
----------	---	---------	---	-----------	---	-----------	---	-----------	---	----------	---

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS
(USE OTHER SIDE IF NECESSARY).

N/A

INSPECTING OFFICER

SIGNATURE *Michael C. Hollis*

PRINT FULL NAME
Michael C. Hollis

TYPE II PERMIT NUMBER/EXPIRATION DATE
220125 05/29/2014

TELEPHONE NUMBER
(660) 263-0346

RETURN COMPLETED REPORT TO THE: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Blvd.
Poplar Bluff, MO 63901



GUTH LABORATORIES, INC.

590 NORTH 67th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-664-6470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 13100 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on April 29, 2013, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1214% (w/vol) ethyl alcohol. The expiration date for this lot number is April 23, 2015 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
MOBERLY POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 942061
01/27/14

ARREST TIME: 04:12

SUBJECT NAME:

BLANK TEST

DATE: 01/21/14 SEX: M

PERMIT NUMBER: 222137

EXPIRATION DATE: 03/29/14

MISCELLANEOUS DATA:

OFFICER I.D.:

TESTING OFFICER:

01/21/14

OFFICER I.D.:

PERMIT NUMBER: 222137

EXPIRATION DATE: 03/29/14

MISCELLANEOUS DATA:

--- INTERNAL ANALYSIS ---

BLANK TEST	0.00	0.00
INTERNAL STANDARD	0.00	0.00
SUBJECT SAMPLE	0.00	0.00
BLANK TEST	0.00	0.00

Michael C. Kelly

Signature

2208-02

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
MOBERLY POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 942061
01/27/14

TESTING OFFICER:

01/21/14

OFFICER I.D.:

PERMIT NUMBER: 222137

EXPIRATION DATE: 03/29/14

MISCELLANEOUS DATA:

--- SUPERVISOR NOTE ---

BLANK TEST	0.00	0.00
INTERNAL STANDARD	0.00	0.00
EXTERNAL STANDARD	0.00	0.00
BLANK TEST	0.00	0.00
EXTERNAL STANDARD	0.00	0.00
BLANK TEST	0.00	0.00
EXTERNAL STANDARD	0.00	0.00
BLANK TEST	0.00	0.00

N = 3
GIV. = .1
BAC = .0013

Michael C. Kelly

Operator Signature

2208-02

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
WINCHESTER POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 940044
01/07/14

ARREST TIME: 04:12

SUBJECT NAME:

SP1/TEST

DOB: 01/01/81 SEX: M

STATE/D.L.: MO/

ARRESTING OFFICER:

MR

OFFICER I.D.:

TESTING OFFICER:

HOLLIS/MO

OFFICER I.D.:

PERMIT NUMBER: 222135

EXPIRATION DATE: 05/09/14

MISCELLANEOUS DATA:

--- BATTERY CHECK ---

BLANK TEST

INTERNAL STANDARD

RADIO INTERFERENCE

Operator Signature



2208-02

Face This Side Down - This Edge In First

BAC DataMaster Evidence Ticket

STATE OF MISSOURI
WINCHESTER POLICE DEPARTMENT

BAC DATA MASTER SERIAL NUMBER 940044
01/07/14
03:12

--- BATTERY CHECK ---

COMPUTER: OKAY

PROPERTY (04-07-2039): OKAY

WEIGHTS
SAMPLE CHAMBER: 49g

FLOW DETECTOR: OKAY

PUMP
HIGH SPEED: OKAY

DETECTOR: OKAY

FILTERS: OKAY

QUARTZ STANDARD: OKAY

CALIBRATION: OKAY

PRINTER TEST

!@#\$%^&'()*+,-./0123456789:;[\] ^ _ ` { | } ~
ABCDEFGHIJKLMNPOQRSTUVWXYZ[\] ^ _ ` { | } ~
abcdefghijklmnopqrstuvwxyz(i)++

Operator Signature

