

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES

STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

665064.82

Complete this report in duplicate at the time of the regular monthly preventative maintenance Send copy to Department of Health and Senior Services; retain original in department file.											
ALCO SENSOR IV SN 030794				84,9324.031				DATE OF INSPECTION 1-27-20/5 TIME OF INSPECTION			2
1781 Zunbehl Rd. St. Charles Mo. 63303											
CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.											
DIGITAL READOUT (ALL ELEMENTS OPERATIONAL) OK											
TEMPERATURE OF ALCO SENSOR (10°C - 40°C)											
PRINTER W	PRINTER WORKING PROPERLY OF										
TIME AND DATE DISPLAYING PROPERLY OK											
BREATH ALCOHOL ACCURACY STANDARDS											
SIMULATOR								D ETHANOL-G			
STANDARD	SUPPLI	er C.H	Lal	ovativie	<u>ک</u> L	от # <u>_</u> /_/	030	EXP. DATE	1-2	10-20/6	
SIMULATOR TEMPERATURE (34°C ± 0.2°C) 34,0 SIMULATOR SN SD 2248 SIMULATOR EXP DATE 1-15-2016											
CALIBRATION CHECK – (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE 0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040% STANDARD - MUST READ BETWEEN 0.038% and 0.042% INCLUSIVE											
TEST 1 *	098	<u> </u>	Т	EST 2 🕶	<u> </u>	97		TEST 3 🕶	.0	98	
RFI DETECTOR OPERATING											
INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS)											
REFUSALS		(004)		(.0509)	0	(.1014)	0	(.1519)	}	(OVER .19)	5
List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary). replaced 9V Duracell bottomy / D.A. 196 1-27-2015											
replaced	90	Durace	11 bo	ttery /D	A.196	, 1-2.)-20/5				***************************************
. 4											secretaries e sele
	erstre soos estimation	- 4									
INSPECTIVE OF	aa(ल⊒:⊪ /	Δ <i>[]</i>		/96			And the second	PRINT NAME	' 1/	1 196	
> <u>P</u> () ()	<u>konst.</u> Berenal	11/45 2011 - 119						i Dayaya Dawaya	////	<u>.</u>	
20 - 20 - 40 <u>- 42 - 42 - 42 - 42 - 42 - 42 - 42 - 4</u>				in the section of the	. f			(() () () () () () () () () (it,4_ [) 704 } 204	*
seigmos musėk	ed rapor			one, Program. es Boulevard	MC Dir	jan nan tê	Haallt i	TO BETRU		•	



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 14030 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on January 22, 2014, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1215% (w/vol) ethyl alcohol. The expiration date for this lot number is January 20, 2016 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is some prior to each use utilizing NIST traceable weights.

TEST RECORD 01022

Temp Date Time 210L and the same of th

Air Blank: 01/27/15 08:55 .000 Calibration Check: 22 01/27/15 08:55 .698

Subject Mame

Subject I.M.

Granator Name, I.D.

Location

1781 Zumbeh

St. Charles, M.

AS IV Serial no: 030794 Version no: 004C

TEST RECORD 01020

ากลโ Date Time 210L

and the same of th Air Blank: 91/27/15 08:51 .000 Calibration Check: 21 01/27/15 08:51 .098

Subject Name

Subject I.D.

Theralar, Name, I.D.

Location

1781 Zunbehl St. Charles, M.

AS IV Serial no: 030794 Version no: 004C

TEST RECORD 01023

Temp Date Time 210L المراكبة والمحار المسريس مساولا والإراجة المساوية والإراد المساوية والإراد المساوية والأراد المساوية

Woid: RFI 12 01/27/15 08:56

Subject Name

Subject I.D.

Operator/Hame, I.D.

Location

1781 Zumbeh/

AS IV Serial no: 030794 Version no: 004C

TEST RECORD 01021

37 Teme Date Time 210L and the second s

Air Blank: 01/27/15 08:53 .000 Calibration Check: 22 91/27/15 98:53 .697

Subject Name

Subject I.D.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES **BREATH ALCOHOL PROGRAM**



PERMIT TYPE II

DANIEL ALLEN

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 1/20/2015	We in Sec
	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
NUMBER 250018	Dal Vasterly
EXPIRES 1/20/2017	- acting director
AO 580-0771 (6-10)	DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

