

MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES

STATE PUBLIC HEALTH LABORATORY

ALCO-SENSOR IV WITH PRINTER MAINTENANCE REPORT

RECEIVED

narom w

By Carol Day at 1:24 pm, Jan 28, 2015 Complete this report in duplicate at the time of the regular monthly preventative maintenance check, and whenever insurament is repaired. Send copy to Department of Health and Senior Services; retain original in department file. ALCO SENSOR IV SN PRINTER SN 1-27-2011 LOCATION OF INSTRUMENT (STREET AND CITY) CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked Items must be corrected before using instrument. DIGITAL READOUT (ALL ELEMENTS OPERATIONAL) OK TEMPERATURE OF ALCO SENSOR (10°C - 40°C) PRINTER WORKING PROPERLY TIME AND DATE DISPLAYING PROPERLY BREATH ALCOHOL ACCURACY STANDARDS SIMULATOR SOLUTION EXP. DATE 1-20-201 LOT# STANDARD SUPPLIER (SIMULATOR EXP DATE 1-15-24/L SIMULATOR SN Sb 224 8 SIMULATOR TEMPERATURE (34°C ± 0.2°C) CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT) Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less/Check the box corresponding to the standard solution being used. (PRINTOUT ATTACHED) 0.100% STANDARD - MUST READ BETWEEN 0.095% and 0.105% INCLUSIVE -0.080% STANDARD - MUST READ BETWEEN 0.076% and 0.084% INCLUSIVE 0.040%-STANDARD_MUST-READ BETWEEN 0.038% and 0.042% INCLUSIVE-TEST 2 P TEST 1 4 T RFI DETECTOR OPERATING INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT: (DO NOT INCLUDE SELF-ADMINISTERED TESTS) REFUSALS (0 - .04)(.05-.09)(.10-.14)(.15-.19) List any new parts and describe any alteration or modification that was made to restore the instrument to operate satisfactorily and within established limits (use other side if necessary).

Return completed report to the: Breath Alcohol Program, MO Department of Health and Sector Sections, Southwest Citation Office

2875 James Boutevard



CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 14030 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on January 22, 2014, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1215% (w/vol) ethyl alcohol. The expiration date for this lot number is January 20, 2016 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is some prior to each use utilizing NIST traceable weights.

AS IV Serial no: 108268 AS IV Serial no: 108268 Version no: 532B Version no: 532B TEST RECORD 00024 9/ Date Time 210L Air Blank: 01/27/15 09:18 .000 Calibration Check: 21 01/27/15 09:18 .100 Subject Name Subject I.D.

Operator Name, I.D. Location

TEST RECORD 00026 9/ Time 210L Date Temp Air Blank: 01/27/15 09:22 .000 Calibration Check: 22 01/27/15 09:22 .101 Subject Name Subject I.D. Operator Name, I.D.

AS IV Serial no: 108268 Version no: 532B

TEST RECORD 00025

Temp Date Time 210L Air Blank: 01/27/15 09:20 .000 Calibration Check: 21 01.727/15 09:20 .101

Subject Name

Subject I.D.

Operator Hame- I.D. 11/12 116

AS IV Serial no: 108268 Version no: 532B

TEST RECORD 00027

9/ Time 210L Teme Date VOID: RFI 12 01/27/15 09:23

Subject Name

Subject I.D.



STATE OF MISSOURI

DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM



PERMIT TYPE II

DANIEL ALLEN

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, INTOX EC/IR II

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 1/20/2015	Was in Sec
	DIRECTOR OF STATE PUBLIC HEALTH LABORATORY
NUMBER 250018	Dal Vasterly
EXPIRES 1/20/2017	
NO 580-0771 (6-10)	DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

