



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
BREATH ALCOHOL PROGRAM

RECEIVED

By Carol Day at 2:17 pm, Apr 30, 2015

INTOX EC/IR II MAINTENANCE REPORT

REPORT #3

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days). Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service. Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

INTOX EC/IR II SN
12842

NAME OF AGENCY
St Charles Police

DATE OF INSPECTION
04/30/2015

LOCATION OF INSTRUMENT (STREET AND CITY)
1781 ZUMBEHL RD ST CHARLES

TIME OF INSPECTION
14:02 CDT

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or is operating within established limits. (Write in observed values where determined). Unmarked items must be corrected before using instrument.

☒ **DIAGNOSTIC RECORD**

☒ BLANK CHECK

☒ CO2 CHECK

☒ FC 1 TEMP

☒ FLOW CHECK

☒ SRC TEMP

☒ FCB CHECK

☒ DET TEMP

☒ CRC COMP CHECK

☒ BT TEMP

☒ CRC CAL CHECK

☒ STD 2 TEMP

☒ PRINT TEST

☒ ETH CHECK

BREATH ANALYZER ACCURACY STANDARDS

☒ SIMULATOR SOLUTION

☐ COMPRESSED ETHANOL-GAS MIXTURE

☒ STANDARD SUPPLIER GUTH

LOT# 14030

EXP. DATE 01/20/2016

☒ SIMULATOR TEMP (34°C ±0.2°C)

SIMULATOR S/N

SIMULATOR EXP DATE

34°C +/- .2°

SD2248

01/15/2016

☒ **CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)**

Run three tests using a standard solution. All three tests must be within +5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

☒ 0.10% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE

☐ 0.08% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE

☐ 0.04% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE

TEST 1 ~ 0.102 g/210L

TEST 2 ~ 0.102 g/210L

TEST 3 ~ 0.102 g/210L

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:

REFUSALS	1	0-.04	0	.05-.09	0	.10-.14	0	.15-.19	0	OVER .19	1
----------	---	-------	---	---------	---	---------	---	---------	---	----------	---

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS (USE OTHER SIDE IF NECESSARY).

INSPECTING OFFICER

SIGNATURE

P.O. Daniel Allen 176

PRINT FULL NAME

ALLEN, DANIEL

TYPE II PERMIT NUMBER

250018

EXPIRATION DATE

01/20/2017

TELEPHONE NUMBER

(636) 949-3300

RETURN COMPLETED REPORT TO THE:

Breath Alcohol Program, Missouri Department of Health and Senior Services,
Southeast District Office, 2875 James Blvd, Poplar Bluff, MO 63901



GUTH LABORATORIES, INC.

590 NORTH 87th STREET • HARRISBURG, PA 17111-4511 • TELEPHONE: 717-664-5470

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 14030 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on January 22, 2014, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1215% (w/vol) ethyl alcohol. The expiration date for this lot number is January 20, 2016 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Ted L. Pauley, President
GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN122211-02 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.