



MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES
STATE PUBLIC HEALTH LABORATORY
BREATH ALCOHOL PROGRAM
DATAMASTER MAINTENANCE REPORT

RECEIVED

By Carol Day at 6:29 am, Feb 09, 2015

Complete this report at the time of the regular monthly preventive maintenance check (not to exceed 35 days).
Complete this report whenever the instrument is serviced or repaired and whenever it is placed into service.
Retain the original and send a copy within 15 days to the Breath Alcohol Program, DHSS.

DATAMASTER SN 201302	NAME OF AGENCY St. Joseph Police Department	DATE OF INSPECTION 02-07-15
LOCATION OF INSTRUMENT (STREET AND CITY) 501 Faraon St. Joseph MO 64501		TIME OF INSPECTION 2023

CHECKLIST: Place a mark in the box by each item if found to be satisfactory or if operating within established limits. (Write in observed values where determined.) Unmarked items must be corrected before using instrument.

<input checked="" type="checkbox"/> DIAGNOSTIC CHECK (PRINTOUT ATTACHED)	DATE AND TIME (from printout) 02/07/15 20:23
<input checked="" type="checkbox"/> COMPUTER	<input checked="" type="checkbox"/> DETECTOR
<input checked="" type="checkbox"/> PROGRAM	<input checked="" type="checkbox"/> FILTERS
<input checked="" type="checkbox"/> HEATERS SAMPLE CHAMBER 49 °C	<input checked="" type="checkbox"/> QUARTZ STANDARD
<input checked="" type="checkbox"/> FLOW DETECTOR	<input checked="" type="checkbox"/> CALIBRATION
<input checked="" type="checkbox"/> PUMP HIGH SPEED	<input checked="" type="checkbox"/> PRINTER

☒ INDICATOR LIGHTS

☒ SIMULATOR SOLUTION SUPPLIER RepCo Marketing Inc. LOT # 14001 EXRDATE 04-30-16

☒ SIMULATOR TEMP (34°C ± 0.2°C) 34.0 °C SIMULATOR SN SD2278 EXP. DATE 11-17-2015

☒ CALIBRATION CHECK - (ONLY ONE STANDARD IS TO BE USED PER MAINTENANCE REPORT)

Run three tests using a standard solution. All three tests must be within ±5% of the standard value and must have a spread of .005 or less. Mark the box corresponding to the standard solution being used. (PRINTOUT ATTACHED)

- ☒ 0.100% STANDARD - MUST READ BETWEEN 0.095% AND 0.105% INCLUSIVE
☐ 0.080% STANDARD - MUST READ BETWEEN 0.076% AND 0.084% INCLUSIVE
☐ 0.040% STANDARD - MUST READ BETWEEN 0.038% AND 0.042% INCLUSIVE

TEST 1 - .100	TEST 2 - .100	TEST 3 .100
---------------	---------------	-------------

☒ PERFORM R.F.I. TEST (PRINTOUT ATTACHED)

INDICATE THE NUMBER OF BREATH TESTS IN THE FOLLOWING RANGES SINCE THE LAST MAINTENANCE REPORT:
(DO NOT INCLUDE SELF-ADMINISTERED TESTS)

REFUSALS 0	(0-.04) 0	(.05-.09) 0	(.10-.14) 1	(.15-.09) 1	(OVER .19) 1
------------	-----------	-------------	-------------	-------------	--------------

LIST ANY NEW PARTS AND DESCRIBE ANY ALTERATION OR MODIFICATION THAT WAS MADE TO RESTORE THE INSTRUMENT TO OPERATE SATISFACTORILY AND WITHIN ESTABLISHED LIMITS
(USE OTHER SIDE IF NECESSARY).

Replaced printer ribbon.

INSPECTING OFFICER

SIGNATURE 	PRINT FULL NAME Wayne Byrom
TYPE II PERMIT NUMBER/EXPIRATION DATE 240241 05-19-2016	TELEPHONE NUMBER 816-271-5359

RETURN COMPLETED REPORT TO THE: Breath Alcohol Program, MO Department of Health and Senior Services, Southeast District Office
2875 James Blvd.
Poplar Bluff, MO 63901

CERTIFICATE OF ANALYSIS

MANUFACTURER AND SUPPLIER: RepCo Marketing, Inc.

LOT NUMBER: 14001

EXPIRATION DATE: April 30, 2016 at 11:59 p.m.

RepCo Marketing, Inc. certifies the following:


RepCo Marketing, Inc. manufactured, tested and supplied Lot Number 14001 of Alcohol Certified Solution for simulators. Random samples of said lot number were analyzed by an independent laboratory utilizing a gas chromatograph and found to contain .1216 gms/dl +/- .003 gms/dl wt/vol ethanol (95% Confidence).

The alcohol and distilled water used in the solution were found to be free of any interfering substance.

This solution will produce a vapor alcohol value of .100 +/- 3% gms/210L Breath when heated to 34 Degrees Celsius +/- 0.2 Degrees Celsius in a simulator (95% Confidence).

The date of manufacture for this lot number is May 1, 2014
The expiration date for this lot number is April 30, 2016 at
11:59 p.m.

This document is a true representation of the original Certificate of Analysis.



Cecil B. Garner, President
RepCo Marketing, Inc.

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
ST. JOSEPH POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201302
02/07/15

TESTING OFFICER:

BYFROM/W/G

OFFICER I.D.: 7054

PERMIT NUMBER: 240241

EXPIRATION DATE: 05/19/16

MISCELLANEOUS DATA:

— — — SUPERVISOR MODE — — —

BLANK TEST	.000	21:02
INTERNAL STANDARD	VERIFIED	21:02
EXTERNAL STANDARD	.100	21:02
BLANK TEST	.000	21:03
EXTERNAL STANDARD	.100	21:03
BLANK TEST	.000	21:04
EXTERNAL STANDARD	.100	21:04
BLANK TEST	.000	21:05

112

$$\text{SIM}_i = .1$$
$$W_G = .1$$

OR SIGNATURE

X No.

REORDER ALL SUPPLIES FROM N.P.A.S.
P.O. BOX 1435, MANSFIELD, OH 44901

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
ST. JOSEPH POLICE DEPARTMENT

300 DATAMETER SERIAL NUMBER 201362
 60707/15
 28123

--- DISH 1076 CHECK ---

COMPUTER ONLY

153701 (54-97-2039): OKAY

LETTER -

SAMPLE DIRECTOR: 490

F-02 REJECTED: OKAY

1977

11:11 AM 02/04/97

REC'D: 2500

CLASS PAGE

CLASS: STENOGRAPHY PAGE: 10

151701794 0609

PRINTED TEST

```
1"428'X)81,-./0123456789!;(<=>?@ABCDEFGH  
IJKL MNOPQRSTUVWXYZ\]^_`abcdefghijklmnopqrstuvwxyz  
~{|}~<br>+http://www.113.org
```

OPERATOR SIGNATURE

Card Stock No.
60021

REORDER ALL SUPPLIES FROM N.P.A.S.
P.O. BOX 1435, MANSFIELD, OH 44901

FACE THIS SIDE DOWN - THIS EDGE IN FIRST

BAC DataMaster

Evidence Ticket

STATE OF MISSOURI
ST. JOSEPH POLICE DEPARTMENT

BAC DATAMASTER SERIAL NUMBER 201302
02/07/15

ARREST TIME: 01:00

SUBJECT NAME:

RFI

DOB: 01/01/01 SEX: M

STATE/D.L.: XX/11111

ARRESTING OFFICER:

BYROM

OFFICER I.D.: BYROM/W/G

TESTING OFFICER:

BYROM/W/G

OFFICER I.D.: 7054

PERMIT NUMBER: 240241

EXPIRATION DATE: 05/19/16

MISCELLANEOUS DATA:

RFI TEST

--- BREATH ANALYSIS ---

BLANK TEST	.000	20:35
INTERNAL STANDARD	VERIFIED	20:35
RADIO INTERFERENCE		

OPERATOR SIGNATURE

Card Stock No.
60021

REORDER ALL SUPPLIES FROM N.P.A.S.
P.O. BOX 1435, MANSFIELD, OH 44901



STATE OF MISSOURI
DEPARTMENT OF HEALTH AND SENIOR SERVICES
BREATH ALCOHOL PROGRAM

2

**PERMIT
TYPE II**

WAYNE BRYOM

is hereby authorized to instruct and supervise operators, train instructors, inspect, calibrate, perform field service and repairs, and operate the following breath analyzer(s):

ALCO-SENSOR IV WITH PRINTER, DATAMASTER

for the determination of the alcoholic content of blood from a sample of expired air. Permit issued under the provisions of sections 577.020 through 577.041, RSMo and 306.111 through 306.119 RSMo.

DATE 5/19/2014

NUMBER 240241

EXPIRES 5/19/2016

DIRECTOR OF STATE PUBLIC HEALTH LABORATORY

DIRECTOR OF DEPARTMENT OF HEALTH AND SENIOR SERVICES

MO 680-0771 (6-10)

LAB-4 (R6-10)

	STATE OF MISSOURI DEPARTMENT OF HEALTH AND SENIOR SERVICES BREATH ALCOHOL PROGRAM
	INSTRUMENT OPERATOR CARD
<small>The named cardholder is authorized to operate an evidential breath alcohol instrument for the determination of the alcoholic content in breath form of expired air in Missouri.</small>	
Operator BRYOM, WAYNE Permit No 240241 Date Issued 5/19/2014 Date Expires 5/19/2016	